

VEGETABLE NEMATODES (Commercial Production)

Terry Kirkpatrick and Cliff Coker

Nematode	Nematicide	Formulation	Active Ingredient	Rate/Acre	Comments
Root Knot, Lesion, Stubby Root and Reniform	Telone II	Liquid	1,3-dichloropropene	See label.	Inject 12 inches below planting depth and seal immediately with appropriate bedding equipment. Wait 7 - 14 days before planting.
	K-Pam or Vapam	Liquid	potassium N-methyldithiocarbamate or sodium methyldithiocarbamate	See label.	Inject 12 inches below planting depth and seal immediately 14 - 21 days before planting.

RESTRICTED USE PESTICIDES – For sale and use only by licensed/certified applicators or persons under their direct supervision. **These are dangerous pesticides – use caution in handling and read and follow current label directions.** If nematodes are suspected to be causing problems, a diagnostic soil sample should be taken to the county agent for submission to the Cooperative Extension Service Nematode Diagnostic Laboratory. **A small fee is required.**